


PMode [2:0]			Description
2	1	0	
0	0	0	10BT Half-duplex, Auto-negotiation disabled
0	0	1	10BT Full-duplex, Auto-negotiation disabled
0	1	0	100BT Half-duplex, Auto-negotiation disabled
0	1	1	100BT Full-duplex, Auto-negotiation disabled
1	0	0	100BT Half-duplex, Auto-negotiation enabled
1	0	1	Not used
1	1	0	Not used
1	1	1	All capable, Auto-negotiation enabled



(1) Options -For EMI reduction.

a. Apply Damping resistors.

(In our case, 330hm was best for EMI reduction.)

b. Do not place power jack nearby RJ-45 connector.

c. Void power and ground planes under discrete magnetic components.

d. Use equal length differential MDI (Medium Dependent Interface) signal traces.

e. Use stable power source.

f. Use high quality CAT5E.

g. Use ferromagnetic bead between digital vdd and analog vdd.

(Impedance of between 100 and 2000 ohms at 100MHz is adequate.)

Title

WIZnet W5500 Referen Schematic

Size

Number

Reference

A3

2026/8/10

Sheet of

File:

Down By